

Rotary Encoder Switch:

Switch Position	S1	S2	S3	S4	S5	S6
0						
1						
2						
3						
4						
5						
6						
7						
8						
9						


a green field = connection

for example:

switch position 5:
S1, S3 and S5 are connected

S2 seems to be unused, but it's connected to VCC → i don't know why

PCB from Transmitter MC-16 (TOP / Parts Side)



Connectors to memory expansion module

Reverse engineered by <http://www.vpippan.at>

File:

Sheet: /

Title: Graupner 4806/24 Speichererweiterung

Size: A4

Date: 9 apr 2013

Rev: A

KiCad E.D.A. eschema (2013-03-31 BZR 4008)-stable

Id: 1/1